

SEAL IDENTIFICATION

First determine the shaft size before continuing.



A) Identify Stationary:

1. Identify shape – cup, o-ring etc.











O-R With

ting Gasket Pin Outside Mo

2. Determine stationary sizes:



i. Housing bore size – measure with vernier or inside calipers.



- If housing is not available, measure OD of rubber with zero compression. Allow us to make provision for the compression to improve accuracy.
- iii. Stationary height (working height):



- O-Ring type, measure from face to back of o-ring.



- Cup type, measure from face to back of cup.



 Centre o-ring type, measure from face to back of stationary.

www.mechanicalsealsinternational.com.au

Facebook: Select Seals And Services Pty Ltd • Skype: selectseals • Google+: Select Seals & Services Pty Ltd





SEAL IDENTIFICATION

B) Identify Rotary:

1. Identify shape/type – rubber bellows, single spring, mul.ple spring, o-ring, PTFE wedge, automotive, button etc.



Rubber Bellow Parallel Spring



O-Ring / PTFE Wedge Multiple Spring



O-Ring Tapered Spring



Metal Bellows



O-Ring Wave Spring

2. Determine rotary seal sizes:



i. OD of Seal.

- ii. Working length:
 - This is the length of the space that the rotary will occupy during operation.



iii. Often it is not easy to gain access to the equipment, then the free length will help to identify the seal. Measure from face to back of seal in uncompressed state.